

FAST-STAT Installation Guide C

Model 1000 used to extend wiring to a heat pump.

In this example a 3-wire cable has been used with a model 1000 and a 2nd transformer has been installed.

It is important that the 2nd transformer is connected in parallel to the furnace / fan coil transformer. If the transformers are connected in series by error then the control voltage would be 48 volts and the controls may be damaged.

